

Contents

Chapter 1 Safety Information and Precautions	1
1.1 Electrical Safety	1
1.2 Machine/System Design and Safety of Personnel	1
1.3 Working Environment and Handling	1
1.4 Electrical Installation - Safety	1
1.5 Before Use	2
Chapter 2 Product Information	3
2.1 Naming rules and rated parameters	3
2.2 Specification and rated parameters	3
2.3 Technical specifications	4
Chapter 3 Installation and Wiring	6
3.1 Control Terminal Specification	6
3.2 Wiring mode of Electric.al circuit	9
3.3 Product dimensions	12
Chapter 4 Keyboard Operation Instructions	13
4.1 Keyboard appearance	13
4.2 Key function	13
4.3 Indicator light description	14
Chapter 5 Function Parameter Table	17
5.1 Description of the meanings in the function code parameter brief table	17
5.2 Basic parameters	17
5.3 Terminal input function selection	41
b5.4 Terminal output function selection	41
5.5 Monitoring code	42
5.6 Fault code table	43
Chapter 6 Regular Inspection and Maintenance	47
6.1 Inspection	47
6.2 Product storage	48

Chapter 7 Operation Guidance 49

 7.1 Asynchronous Motor Pump Drive Operation Guidance 49

 7.2 Synchronous Motor Pump Drive Operation Guidance 49

 7.3 Introduction of photovoltaic water pump function 50

Appendix1:Modbus Communication Protocol 52

Chapter 1 Safety Information and Precautions

1.1 Electrical Safety

Extreme care must be taken at all times when working with the inverter or within the area of the inverter. The voltages used in the inverter can cause severe electrical shock or burns and is potentially lethal. Only authorized and qualified personnel should be allowed to work on inverter.

1.2 Machine/System Design and Safety of Personnel

- Machine/system design, installation, commissioning startups and maintenance must be carried out by personnel who have the necessary training and experience. They must read this safety information and the contents of this manual. If incorrectly installed, the inverter may present a safety hazard.
- The inverter uses high voltages and currents, carries a high level of stored electrical energy in the DC bus capacitors even after power OFF. These high voltages are potentially lethal.
- The inverter is NOT intended to be used for safety related applications/functions. The electronic "STOP & START" control circuits within the inverter must not be relied upon for the safety of personnel. Such control circuits do not isolate mains power voltages from the output of the inverter. The mains power supply must be disconnected by a electrical safety isolation device before accessing the internal parts of the inverter.
- Safety risk assessments of the machine or process system which uses an inverter must be undertaken by the user and or by their systems integrator/designer. In particular the safety assessment/design must take into consideration the consequences of the inverter failing or tripping out during normal operation and whether this leads to a safe stop position without damaging machine, adjacent equipment and machine operators/users. This responsibility lies with the user or their machine/process system integrator.

1.3 Working Environment and Handling

Matters related to transport, storage, installation, IP rating, working environment and inverter tolerance limits (temperature, ambient, voltage, pollution, vibration etc) can be found within this manual. The guidelines and recommendations should be followed in order to gain long term trouble free operation as the lifetime of the inverter is dependent on the working environment and correct handling of the product in the initial installation stage.

1.4 Electrical Installation - Safety

- Mains power supply isolation switch should be fitted to the inverter. The mains power supply must be disconnected via the isolation switch before any cover of the inverter can be removed or before any servicing work is undertaken.
- Stored charge in the DC bus capacitors of the inverter is potentially lethal after the mains power has been disconnected. The mains power must be isolated at least 10 minutes before any work can be undertaken as the stored charge will have been discharged through the internal bleed resistor fitted across the DC bus capacitors. .
- Power wire, motor wire and control wire should be all connected firmly. Earth must be reliable and earth resistance must be lower than 10Ω;
- Human body electrostatic will damage inner sensitive components seriously. Before operation, please follow ESD measures. Otherwise, there is danger of inverter damage;
- Inverter output voltage is pulse wave. If components such as capacitor which improves power factor and

pressure-sensitive resistance for anti-thunder and so on are installed at the output side, please dismantle them;

- No switch components such as breaker and contactor at the output side (If there must be one, please make sure the output current is 0 while the switch acting);
- No matter where the fault is, there is danger of serious accident. So there must be additional external prevent measures or other safety devices;
- Only used in application fields as maker stated. No use in equipments related to special fields such as emergency, succor, ship, medical treatment, aviation, nuclear and etc;

1.5 Before Use

On receiving your order, please check the package and confirm intact before opening, and check if there's any damage, scratch or dirt (damages caused during transportation are not within the company's warranty). If there's any damage caused during transportation, please contact us or the transport company immediately. After confirming the receipt of the goods intact, please re-confirm if the product and your order are consistent.

Chapter 2 Product Information

2.1 Naming rules and rated parameters

PV210 - 4T - 7.5G (H)
①
②
③
④
⑤

Field	Identification	Label description
Drivers series	①	PV210 series Solar photovoltaic water pump inverter
Voltage level	②	1T:DC60V—DC400V, Suitable for driving pumps with 110VAC 2T:DC60V—DC450V, Suitable for driving pumps with 220VAC 4T:DC200V—DC800V, Suitable for driving pumps with 380VAC
Adaptive motor power	③	0.75:0.75KW 1.5:1.5KW 2.2:2.2KW 3.7: 3.7KW 5.5:5.5KW 7.5:7.5KW
Inverter type	④	G:Type G machine
Suffix	⑤	2T:Support up to 500V input 4T:Support up to 900V input

2.2 Specification and rated parameters

SN	Models	Output current(A)	Output frequency range	Applicable for pumps
1T type: 60V DC to 400V DC input , Output:3-phase 110 ~ 230VAC, suitable for AC110 pump				
1	PV210-1T-0.75G	7A	0~600Hz	0.75KW
2	PV210-1T-1.5G	10A	0~600Hz	1.5KW
3	PV210-1T-2.2G	16A	0~600Hz	2.2KW
2T type: 60V DC to 450V DC input (With suffix "H" support up to 500V input), output:3-phase 220 ~ 240VAC, suitable for AC220 pump				
4	PV210-2T-0.75G	4A	0~600Hz	0.75KW
5	PV210-2T-1.5G	7A	0~600Hz	1.5KW
6	PV210-2T-2.2G	10A	0~600Hz	2.2KW
7	PV210-2T-3.7G	16A	0~600Hz	3.7KW
4T type: 200V DC to 800V DC input (With suffix "H" support up to 900V input), output:3-phase 230 ~ 460VAC,suitable for AC380 pump				
8	PV210-4T-3.7G	10A	0~600Hz	3.7KW
9	PV210-4T-5.5G	14A	0~600Hz	5.5KW
10	PV210-4T-7.5G	18A	0~600Hz	7.5KW

2.3 Technical specifications

Item		Specification
Power input	Voltage	1T: 60V DC to 400V DC 2T: 60V DC to 500V DC 4T: 200V DC to 900V DC
Power output	Adaptive motor type	Three-phase asynchronous motor, permanent magnet synchronous motor
	MPPT efficiency	maximal efficiency ≥99%
	Output voltage	1T:3-phase 110 ~ 230VAC 2T:3-phase 220 ~ 240VAC 4T:3-phase 230 ~ 460VAC inaccuracy<5%
	Output frequency	0~600Hz;unit:0.01Hz
	Overload capacity	G type: 150% rated current/1 min, 180% rated current/10s, 200% rated current/0.5s
Main control performance	Motor control mode	V/F without PG , VC without PG , MPPT
	Speed control range	Vector control without PG, rated load 1:100
	Steady speed	VC without PG: ≤2% rated synchronized speed
	Starting torque	VC without PG: when 0.5Hz, 150% rated torque
	Torque response	VC without PG: ≤20ms;
Product basic functions	Torque boost capacity	Auto torque upgrade 0.0%~100.0%; Manual torque upgrade 0.0%~30.0%
	V/F curve	4 modes: one linearity torque characteristic curve ,one self-setting V/F curve mode, one drop torque characteristic curve (1.1- 2.0 powers),and square V/F curve mode.
	Acceleration /Deceleration curve	2 modes: linear Acceleration/Deceleration and S curve Acceleration/Deceleration.
	Rated output voltage	Rely on power supply voltage compensate function, while motor rated voltage is 100%, set it at the range of 50-100%(output can not over input voltage).
	Auto energy-saving running	While under V/F control mode, according to load situation, auto-optimize output voltage to save energy.
	Standard functions	PID control, speed track, power off restart, jump frequency, upper/lower frequency limit control, program operation, multi- speed, RS485.
	Frequency setting channels	Keyboard digital setting, keyboard potentiometer , Communication given.
	Running command channel	External Keyboard given、DI terminal given, communication given
	Input command signal	Start, stop, FWD/REV, JOG, multi-step speed, reset, ACC/DEC time selection, frequency given channel selection, exterior fault alarm.
Protective function		Overvoltage, under-voltage, current limit, over-current, overload, electric thermal relay, overheat, overvoltage stall, data protection, rapid speed protection, output phase failure protection.
Environment	Install place	altitude ≤ 1000m,above 1000m down the rated amount, each increase of 100m down the rated mount of 1%;no condensation, ice ,rain, snow, hail; solar radiation below 700W/㎡, air pressure 70-106 kPa.
	Temperature, humidity	-10 ~ + 50 ℃, derating above 40 ℃ , maximum temperature 60 ℃ (no-load operation)5% to 95% RH (non-condensing)
	Storage temperature	-20 ~+60℃

Item		Specification
	Protection grade	IP00
	Cooling method	Natural cooling/Forced air cooling

Chapter 3 Installation and Wiring

In order to ensure the safe use of the product by the user, maximize the performance of the inverter, and ensure the reliable operation of the inverter, please use this product strictly in accordance with the environmental, wiring, and ventilation requirements described in this chapter.

3.1 Control Terminal Specification

3.1.1 Schematic diagram of board layout




Fig. 3.1-1 Schematic diagram of the board layout

3.1.2 Function description of the control terminals





Fig. 3.1-2 Control terminals of the board layout

Type	Terminal	Terminal name	Terminal function definition
Power	+24V-COM	External 24V power supply	Provide + 24 V power supply to the outside, and the maximum output is 200mA, Isolated from GND interiorly.
Digital input	DI1-COM	Digital input terminal	1. Optical coupling isolation, compatible with bipolar input, internal impedance 3.6 kΩ . 2. Multi-function digital input, through F5-00 to set the function. Inverter default for the internal supply of +24V power, COM for the common end. 3. When the external power supply is used, the cable connection mode see Figure 3.2-3 and 3.2-5. The voltage range of the external power supply is +24V±10%.
Digital output	DO1	Digital output terminal	Open collector output, programmable action object, maximum output DC24V / 50mA

3.1.3 Communication interface





The RJ45 communication interface includes RS485 of standard Modbus communication and reserved external keyboard. The specific signal definition is as follows:



Pin	Name	Description
1、 2	GND	Power reference ground
3、 4	+5V	+5V power supply
5	RS485-	RS485(MODBUS communication protocol)
7	RS485+	
6	485-	External Keyboard 485 communication (reserved)
8	485+	

3.1.4 Description of connection function of conversion terminal

Function diagram and description of transfer switch

Tag number	Wiring Diagrams	Choose location	Function Description
J27		24V the port	When the OPEN terminal is connected to 24V, the DI and COM short input are valid. Can also use the NPN input type (Factory default).
		COM the port	When dial this end, the OPEN terminal is connected to COM. In this case, the DI and 24V short input are valid. PNP input type is also supported.
J19		OFF	Disconnect RS485 communication terminal resistance (Factory default).
		ON	RS485 communication terminal resistance is connected.

3.2 Wiring mode of Electrical circuit

3.2.1 Wiring Diagram

The wiring mode of the control circuit of the frequency converter is shown in the figure on the following page:




Fig. 3.2-1 Wiring diagram

Notice:

- ① Terminal © Indicates the main loop terminal, o indicates the control loop terminal;
- ② Signal cables and power cables must be routed separately, and the control cables and power cables should be crossed at a 90-degree Angle as far as possible. The analog signal line reference diagram describes the selection of linear, power cable is the best choice of shielded three core cable.

3.2.2 Multi function contact input connection

Multifunctional digital input terminals support NPN or PNP connection type. DI1 terminal is flexibly connected to external devices. You can select the NPN or PNP mode through the jump cap at J27 on the control board (the factory default mode is NPN).

Connection mode of NPN characteristic transistor:




Fig. 3.2-2 NPN mode Uses the internal power supply




Fig. 3.2-3 NPN mode Uses external power supplies

Precautions:

If the external power supply is connected in NPN mode, remove the jump cap in position J27.

Connection mode of PNP characteristic transistor:




Fig. 3.2-4 PNP mode uses an internal power supply




Fig. 3.2-5 PNP mode uses an external power supply

3.3 Product dimensions

The image is a technical drawing of the PV210 solar pump inverter. It shows the internal layout of components including a main control board at the top, several relays or contactors in the center, and four large circular cooling fans on the right side. At the bottom, there are terminal blocks for wiring. Dimensions are indicated: 'W' represents the total width, 'W1' represents the width of the main component area, and 'H' represents the total height. The drawing is a top-down view of the unit's internal chassis.

Inverter model	External dimensions (mm)		Installation dimensions (mm)		Mounting aperture	
	W	H	W1	H1		
PV210-1T-0.75G	140	130	132	122	4-Φ3.5	
PV210-1T-1.5G						
PV210-1T-2.2G	175	190	167	182		
PV210-2T-0.75G(H)	140	130	132	122		
PV210-2T-1.5G(H)						
PV210-2T-2.2G(H)						
PV210-2T-3.7G(H)	175	190	167	182		
PV210-4T-3.7G(H)	145	148	137	140		
PV210-4T-5.5G(H)	175	190	167	182		
PV210-4T-7.5G(H)						

Notice:

- ① 1T-1.5G and below power section, 2T-2.2G and below power section and 4T-3.7G machine wiring should be equipped with type 6.3 spring female spade terminal;
- ② For other power segment models, circular cold pressure OT 4-6 terminal wiring is recommended to ensure reliability.

Chapter 4 Keyboard Operation Instructions

4.1 Operation of Dual-line display LED control panel













Fig. 4.1-1 Dual-line display LED control panel layout and instructions

4.1.1 Key function


Symbol	Key name	Meaning
	JOG/REV	Perform a function switchover as defined by the setting of F7-07
	MENU/ESC	Enter or exit Level 1 menu. Return to the previous menu.
	Increment	When navigating a menu, it moves the selection up through the screens available. When editing a parameter value, it increases the displayed value. When inverter is in RUN mode, it increases the speed.
	Decrement	When navigating a menu, it moves the selection down through the screens available. When editing a parameter value, it decreases the displayed value. When the inverter is in RUNNING mode, it decreases the speed.

Symbol	Key name	Meaning
	Shift	Select the displayed parameter in the STOP or RUNNING status. Select the digit to be modified when modifying a parameter value.
	DAT/ENT	Enter each level of menu interface. Confirm displayed parameter setting.
	Potentiometer	Clockwise rotation increases the operation value, and counterclockwise rotation decreases the operation value.
	RUN	Start the inverter when using the operating panel control mode. It is inactive when using the terminal or communication control mode.
	STOP/RES	Stop the inverter when the drive is in the RUNNING status. Perform a reset operation when the drive is in the FAULT status.





4.1.2 Indicator light description




Status Indicators	Indication
RUN	ON indicates the RUNNING status. OFF indicates the STOP status.
FWD/REV	ON indicates forward motor rotation. OFF indicates reverse motor rotation.
L/R	ON indicates under terminal control. OFF indicates under operating panel control. FLASHING indicates under serial communication control.
Hz	Hz for frequency
A	A for current
V	V for voltage
RPM	RPM for motor speed
%	Percentage

4.2 Operation of Single-line display LED control panel



4.2.1 Key Functions on Control Panel

Symbol	Key name	Meaning
	MENU/ESC	1) Enter or exit Level 1 menu. 2) Return to the previous menu.
	Increment	1) When navigating a menu, it moves the selection up through the screens available. 2) When editing a parameter value, it increases the displayed value. 3) When the Inverter is in RUNNING mode, it increases the speed.
	Decrement	1) When navigating a menu, it moves the selection down through the screens available. 2) When editing a parameter value, it decreases the displayed value. 3) When the Inverter is in RUNNING mode, it decreases the speed.
	Shift/Enter	1) In the stop display interface and the operation display interface, you can select the display parameters. When modifying the parameters, you can select the modification bit of the parameters. Long time ($\geq 1s$), you can enter the menu interface step by step, set parameters to confirm.

Symbol	Key name	Meaning
	RUN	Start the Inverter when using the operating panel control mode. It is inactive when using the terminal or communication control mode.
	STOP/RES	1) Stop the Inverter when the drive is in the RUNNING status. 2) Perform a reset operation when the drive is in the FAULT status.
	Potentiometer	A clockwise rotation increases the operation value and a counterclockwise rotation decreases the operation value.

4.1.2 Status Indicators

Status Indicators	Display light name	Indication
RUN	Running status indication	ON indicates the RUNNING status. OFF indicates the STOP status. Blinking indicates the fault alarm state.
F/R	Forward/Reverse indication	ON indicates forward motor rotation. OFF indicates reverse motor rotation. Blinking indicates the forward/reverse switchover status.
Hz	Frequency indication	Hz for frequency
A	Current indication	A for current
V	Voltage indication	V for voltage
Hz+A	Rotation speed indication	The current displayed parameter is speed, unit: RPM
A+V	Percentage indication	The displayed parameter is percentage (unit: %)

Chapter 5 Function Parameter Table

This chapter just provides function parameter table.

5.1 Description of the meanings in the function code parameter brief table

“●”: Parameter can be changed in the running state.

“○”: Parameter can't be changed in the running state.

“×”: Parameter can be read only.

“_”: Factory setting parameter, only factory can set.

“※”: Parameter is related to the model.

5.2 Basic parameters

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F0-00	Rated current			○	0x000
F0-01	Motor control mode	0	0: VF Control (AM) 1: No PG vector control (AM) 2: With PG vector control (AM) 3: No PG vector control (FM) 4: With PG vector control (FM) 5: VF separation control (AM) 6: 3-line Single-Phase Control (AM)	○	0x001
F0-02	Run command channel	0	0: Keyboard control 1: Terminal control 2: RS485 communication control 3: Optional card	○	0x002
F0-03	Main Frequency reference source A	0	0: Keyboard number given 1: potentiometer of keyboard given 2: Voltage/Current analog AI1 given 3: Voltage/Current analog AI2 given(Expansion card reserved)	●	0x003
F0-04	Auxiliary Frequency reference source B	1	4: Terminal pulse HDI given(Expansion card reserved) 5: RS485 communication given 6: Terminal UP/DW control 7: PID control given 8: Program control (PLC) given 9: Multi-steps speed given 10: Optional card	●	0x004
F0-05	The reference source selection of auxiliary frequency source B	0	0: Max. output frequency as reference source 1: Set frequency of channel A as reference source	●	0x005
F0-06	Frequency given source selection	0	0: Main Frequency reference source A 1: Auxiliary Frequency reference source B 2: A+B 3: A-B 4: Max. value of A and B 5: Min. value of A and B	●	0x006

F0-07	Running Command Binding	0000	Unit: keyboard command instruction binding Tens: terminal command instruction binding Hundreds: communication command instruction binding Thousands: optional card command instruction binding 0: no binding 1: keyboard number given frequency 2: Potentiometer of keyboard given 3: Voltage/Current analog AI1 given 4: Voltage/Current analog AI2 given(Expansion card reserved) 5: Terminal pulse HDI given(Expansion card reserved) 6: RS485 communication given 7: Terminal UP/DW control 8: PID control given 9: Program control (PLC) given A: Multi-steps speed given B: Optional card	●	0x007
F0-08	Keyboard digital setting frequency	50.00Hz	0~upper limit	●	0x008
F0-09	Max frequency output	50.00Hz	upper limit~600.00Hz	○	0x009
F0-10	Upper limit frequency source selection	0	0: Upper limit frequency digital given 1: potentiometer of keyboard given 2: Voltage/Current analog AI1 given 3: Voltage/Current analog AI2 given(Expansion card reserved) 4: Terminal pulse HDI given(Expansion card reserved) 5: RS485 communication given 6: Optional card	●	0x00A
F0-11	Upper frequency limit digital setting	50.00Hz	Lower limit frequency~max frequency	●	0x00B
F0-12	Lower limit frequency	0.00Hz	0.00~upper limit frequency	●	0x00C
F0-13	Lower limit frequency running mode	1	0: Stop output 1: Run at lower limit frequency	○	0x00D
F0-14	ACC time 0	Model set	0.01~650.00s	※	0x00E
F0-15	DEC time 0	Model set		※	0x00F
F0-16	Rotary direction selection	0000	Unit: running direction takes the opposite 0: Direction unchanged 1: Direction takes the opposite Tens:running direction prohibited 0: Forward and reverse commands are allowed 1: Only FWD command allowed 2: Only REV command allowed Hundreds: frequency control direction selection 0: Invalid 1: Valid Thousands: torque control direction selection 0: Invalid 1: Valid	○	0x010
F0-17	PWM carrier frequency	Model set	0.7~16.0kHz	※	

F0-18	PWM control mode	1111	Unit: carrier associated with temperature 0: Temperature independent 1: Temperature dependent Tens: carrier associated with output frequency 0: not associated 1: associated Hundreds: random PWM valid 0: Prohibited 1: Valid Thousands: PWM modulation mode 0: Only use three-phase modulation 1: Two-phase and three-phase modulation automatically switched	●	
F0-19	Parameter initialization	0	0: No action 1: Restore factory default (not restoring motor parameters) 2: Restore factory default (restoring motor parameters) 3: Clear malfunction records		0x013

F1 Start-stop control parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F1-00	Start-up running mode	0	0: Start by start-up frequency 1: DC injection at first then start by start-up frequency 2: Speed tracking, and judge the direction then start	○	0x100
F1-01	Start pre-excitation time	0.00s	0.00~60.00s	○	0x101
F1-02	Start-up frequency	0.50Hz	0.00~60.00Hz	○	0x102
F1-03	Start-up frequency holding time	0.0s	0.0~50.0s	○	0x103
F1-04	DC injection current before start	60.0%	0.0~150.0%	○	0x104
F1-05	DC injection time before start	0.0s	0.0~60.0s	○	0x105
F1-06	Speed tracking time	0.50s	0.00~60.00s	○	0x106
F1-07	Speed tracking delay when stop	1.00s	0.00~60.00s	○	0x107
F1-08	Speed tracking Mode	0010	Unit: The frequency selection of Speed tracking 0: Speed tracking from Max. Output frequency 1: Speed tracking from stop Output frequency Tens: The direction selection of Speed tracking 0: bidirectional 1: Unidirectional	○	0x108
F1-09	Reserved	---	---	○	0x109
F1-10	Stop mode	0	0: DEC stop 1: Free stop	○	0x10A
F1-11	DC braking initial frequency when stop	1.00Hz	0.00~50.00Hz	○	0x10B
F1-12	DC braking current	60.0%	0.0~150.0%		0x10C
F1-13	DC braking hold time when stop	0.0s	0.0~60.0s	○	0x10D
F1-14	Stop detection frequency	0.50Hz	0.00~50.00Hz	●	0x10E
F1-15	Reserved	---	---	---	0x10F

PV210 solar pump inverter user manual

F1-16	ACC/DEC selection	0010	Unit: time base selection 0: max frequency 1: fixed frequency 50Hz 2: set frequency Tens: S ACC/DEC selection 0: Beeline ACC/DEC 1: S Curve ACC/DEC Hundreds & Thousands: reserved	○	0x110
F1-17	ACC start time for S curve	0.10s	0.00~10.00	○	0x111
F1-18	ACC end time for S curve	0.10s	0.00~10.00	○	0x112
F1-19	DEC start time for S curve	0.10s	0.00~10.00	○	0x113
F1-20	DEC end time for S curve	0.10s	0.00~10.00	○	0x114
F1-21	ACC time 1	10.00s	0.01~650.00s	●	0x115
F1-22	DEC time 1	10.00s	0.01~650.00s	●	0x116
F1-23	ACC time 2	10.00s	0.01~650.00s	●	0x117
F1-24	DEC time 2	10.00s	0.01~650.00s	●	0x118
F1-25	ACC time 3	10.00s	0.01~650.00s	●	0x119
F1-26	DEC time 3	10.00s	0.01~650.00s	●	0x11A
F1-27	DEC time at emergency stop	1.00s	0.01~650.00s	●	0x11B
F1-28	FWD&REV dead time	0.0s	0.0~120.0s	○	0x11C
F1-29	Zero speed torque frequency threshold	0.50Hz	0.00~10.00Hz	●	0x11D
F1-30	Zero speed torque coefficient	60.0%	0.0~150.0%	●	0x11E
F1-31	Zero speed torque holding time	0	0.0~6000.0s If set 6000.0S, always hold without time limit	●	0x11F
F1-32~F1-34		Reserved			
F1-35	Power off restart action selection	0	0:Invalid 1:Valid	○	0x123
F1-36	Power off restart waiting time	0.50s	0.00~60.00s	○	0x124
F1-37	JOG running curve setting	1	0:S curve 1:Beeline	○	0x125
F1-38	JOG running frequency setting	5.00Hz	0.00~Max frequency	●	0x126
F1-39	JOG ACC time	10.00s	0.01~650.00s	●	0x127
F1-40	JOG DEC time	10.00s	0.01~650.00s	●	0x128

F2 Motor parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F2-00	Motor mode	0	0: Asynchronous motors (AM) 1: Permanent magnet synchronous motors (PM)	×	0x200
F2-01	Number of motor poles	4	2~98	○	0x201

F2-02	Motor rated power	Model set	0.1~1000.0kW	※	0x202
F2-03	Motor rated frequency	Model set	0.01~max frequency	※	0x203
F2-04	Motor rated speed	Model set	1~65000rpm	※	0x204
F2-05	Motor rated voltage	Model set	0~1500V	※	0x205
F2-06	Motor rated current	Model set	0.1~2000.0A	※	0x206
F2-07	Asynchronous motor no-load current	Model set	0.1~650.0A	※	0x207
F2-08	Asynchronous motor stator resistance	Model set	0.01~50.00%	※	0x208
F2-09	Asynchronous motor rotor resistance	Model set	0.01~50.00%	※	0x209
F2-10	Asynchronous motor stator leakage inductance	Model set	0.01~50.00%	※	0x20A
F2-11	Asynchronous motor stator inductance	Model set	0.1~2000.0%	※	0x20B
F2-12	Synchronous motor stator resistance	Model set	0.01~50.00%	※	0x20C
F2-13	Synchronous motor D-axis inductance	Model set	0.01~200.00%	※	0x20D
F2-14	Synchronous motor Q-axis inductance	Model set	0.01~200.00%	※	0x20E
F2-15	Synchronous motor with a reverse electromotive force	Model set	1~1500V	※	0x20F
F2-16	Synchronous motor encoder installation angle	Model set	0.0° ~360.00°	※	0x210
F2-20	Motor parameters self-adjustment selections	0	0: No operation 1: Rotary type self-tuning 2: Static type self-tuning 3: Stator resistance self-tuning	○	0x214
F2-21	Synchronous machine poles searching function	0010	Unit: closed-loop vector 0: OFF 1: ON 2: On, only operate firstly when electrify Tens: open-loop vector 0: OFF 1: ON 2: ON, only operate firstly when electrify	○	0x215
F2-30	Speed feedback or encoder mode	0000	Unit: encoder mode 0: Common ABZ encoder 1: Resolver encoder Tens: encoder direction 0: same direction 1: reverse direction Hundreds: wire break inspection 0: OFF 1: ON Thousands: Z pulse correction enabled 0: OFF 1: ON	○	0x21E
F2-31	ABZ encoder lines	1024	1	○	0x21F
F2-32	Wire break inspection time	2.000s	0.100~60.000s	●	0x220
F2-33	Resolver encoder poles	2	2~128	○	0x221

F2-36	First-order filter of encoder speed inspection	1.0ms	0.0~100.0ms	●	0x224
-------	--	-------	-------------	---	-------

F3 Vector control parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F3-00	ASR(speed loop) proportional gain 1	10.00	0.01~100.00	●	0x300
F3-01	ASR integral time 1	0.200s	0.000~6.000s	●	0x301
F3-02	ASR filter time1	0.0ms	0.0~100.0ms	●	0x302
F3-03	ASR switch frequency 1	0.00Hz	[F3-07]~Max frequency	●	0x303
F3-04	ASR (speed loop) proportional gain 2	10.00	0.01~100.00	●	0x304
F3-05	ASR (speed loop) integral time 2	0.200s	0.000~6.000s	●	0x305
F3-06	ASR filter time 2	0.0ms	0.0~100.0ms	●	0x306
F3-07	ASR switch frequency 2	0.00Hz	0.00~[F3-03]	●	0x307
F3-08	Electric motor torque limit	250.0%	0.0~400.0%	●	0x308
F3-09	Power generation torque limit	250.0%	0.0~400.0%	●	0x309
F3-10	Current loop D-axis proportional gain	1.000	0.001~4.000	●	0x30A
F3-11	Current loop D-axis integral gain	1.000	0.001~4.000	●	0x30B
F3-12	Current loop Q-axis proportional gain	1.000	0.001~4.000	●	0x30C
F3-13	Current loop Q-axis integral gain	1.000	0.001~4.000	●	0x30D
F3-15	Vector control motor slip compensation	100.0%	0.0~250.0%	●	0x30F
F3-16	Vector control start torque	0.0%	0.0~250.0%		0x310
F3-17	Reserved	---	---		0x311
F3-18	Over excitation braking gain	100.0%	0.0~500.0%	●	0x312
F3-19	Over excitation braking	100.0%	0.0~250.0%	●	0x313
F3-20	Motor constant power area power limit	250.0%	0.0~400.0%	●	0x314
F3-21	Motor weak magnetic current upper limit	60.0%	0.0~250.0%	●	0x315
F3-22	Motor weak magnetic feed forward gain	10.0%	0.0~200.0%	●	0x316
F3-23	Motor weak magnetic gain	10.0%	0.0~500.0%	●	0x317
F3-24	Motor weak magnetic voltage coefficient	97.0%	0.0~120.0%	●	0x318
F3-25	Low frequency pull in current	10.0%	0.0~50.0%	●	0x319
F3-26	High frequency pull in current	10.0%	0.0~50.0%	●	0x31A
F3-27	Frequency of current pulled in	10.0%	0.0~100.0%	●	0x31B

F3-28	Vector control energy saving function	0	0:OFF 1:ON	●	0x31C
F3-29	Energy saving control gain	50.0%	0.0~80.0%	●	0x31D
F3-30	Energy saving control low-pass filter	0.010s	0.000~6.000s	●	0x31E
F3-32	MTPA gain	100.0%	0.0~400.0%	●	0x320
F3-33	MTPA filter time	1.0ms	0.0~100.0ms	●	0x321

F4 V/F control parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F4-00	Linear V/F curve selection	0	0: Beeline VF curve 1-9: 1.1-1.9 power VF curve 10: square VF curve 11: Multi-point V / F (F4-01~F4-10);	○	0x40
F4-01	V / F voltage V1	3.0%	0.0~100.0%	○	0x401
F4-02	V / F frequency F1	1.00Hz	0.00~max frequency	○	0x402
F4-03	V / F voltage V2	28.0%	0.0~100.0%	○	0x403
F4-04	V / F frequency F2	10.00Hz	0.00~max frequency	○	0x404
F4-05	V / F voltage V3	55.0%	0.0~100.0%	○	0x405
F4-06	V / F frequency F3	25.00Hz	0.00~max frequency	○	0x406
F4-07	V / F voltage V4	78.0%	0.0~100.0%	○	0x407
F4-08	V / F frequency F4	37.50Hz	0.00~max frequency	○	0x408
F4-09	V / F voltage V5	100.0%	0.0~100.0%	○	0x409
F4-10	V / F frequency F5	50.00Hz	0.00~max frequency	○	0x40A
F4-11	Output voltage percentage	100.0%	25.0~120.0%	○	0x40B
F4-12	Torque boost	0.0%	0.0~30.0%	●	0x40C
F4-13	Torque boost cut-off frequency	100.0%	0.0~100.0%	●	0x40D
F4-14	V / F slip compensation gain	100.0%	0.0~200.0%	●	0x40E
F4-15	V / F slip compensation limit	100.0%	0.0~300.0%	●	0x40F
F4-16	V / F slip compensation filtering	0.200s	0.000~6.000s	●	0x410
F4-17	Oscillation suppression gain	100.0%	0.0~900.0%	●	0x411
F4-18	Reserved	---	---		0x412
F4-19	V / F automatic energy saving control	0	0: off 1: on	○	0x413
F4-20	Lower limit of energy-saving step-down frequency	15.00Hz	0.0~50.00Hz	○	0x414
F4-21	Energy-saving step-down voltage lower limit	50.0%	20.0~100.0%	○	0x415
F4-22	Energy-saving buck voltage regulation rate	0.010V/mS	0.000~0.200V/mS	●	0x416
F4-23	Energy saving buck voltage pick-up rate	0.200V/mS	0.000~2.000V/mS	●	0x417

F5 Multi-function terminal parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F5-00	DI1 terminal function selection	1	Refer to attached list 5.3	○	0x500
F5-01	DI2 terminal function selection	2	Refer to attached list 5.3	○	0x501
F5-02	DI3 terminal function selection	3	Refer to attached list 5.3	○	0x502
F5-03	DI4 terminal function selection	4	Refer to attached list 5.3	○	0x503
F5-04	DI5 terminal function selection	0	Refer to attached list 5.3	○	0x504
F5-05	DI6 terminal function selection	5	Refer to attached list 5.3	○	0x505
F5-06	DI7 terminal function selection	6	Refer to attached list 5.3	○	0x506
F5-07	DI8 terminal function selection	7	Refer to attached list 5.3	○	0x507
F5-08	DI1~DI4 terminal characteristics selection	0000	0: closed effective 1: open effective Unit: DI1 Tens: DI2 Hundreds: DI3 Thousands: DI4	●	0x508
F5-09	DI5~DI8 terminal characteristics selection	0000	0: closed effective 1: open effective Unit: DI5 Tens: DI6 Hundreds: DI7 Thousands: DI8	●	0x509
F5-10	DI1 valid detection delay	0.010	0.000~6.000s	●	0x50A
F5-11	DI1 invalid detection delay	0.010	0.000~6.000s	●	0x50B
F5-12	DI2 valid detection delay	0.010	0.000~6.000s	●	0x50C
F5-13	DI2 invalid detection delay	0.010	0.000~6.000s	●	0x50D
F5-14	DI3 valid detection delay	0.010	0.000~6.000s	●	0x50E
F5-15	DI3 invalid detection delay	0.010	0.000~6.000s	●	0x50F
F5-16	DI4 valid detection delay	0.010	0.000~6.000s	●	0x510
F5-17	DI4 invalid detection delay	0.010	0.000~6.000s	●	0x511
F5-18	DI5 valid detection delay	0.010	0.000~6.000s	●	0x512
F5-19	DI5 invalid detection delay	0.010	0.000~6.000s	●	0x513
F5-20	DI6 valid detection delay	0.010	0.000~6.000s	●	0x514
F5-21	DI6 invalid detection delay	0.010	0.000~6.000s	●	0x515
F5-22	DI7 valid detection delay	0.010	0.000~6.000s	●	0x516
F5-23	DI7 invalid detection delay	0.010	0.000~6.000s	●	0x517
F5-24	DI8 valid detection delay	0.010	0.000~6.000s	●	0x518
F5-25	DI8 invalid detection delay	0.010	0.000~6.000s	●	0x519
F5-26	Terminal control running mode	0	0: two-wire system 1 1: two-wire system 2 2: Three-wire system 1 3: three-wire system 2	●	0x51A
F5-27	Terminal operate protection	0111	0: off 1: on Unit: terminal start protection when exiting abnormally Tens: Log terminal start protection when abnormal exit Hundreds: start protection when command channel is switched to terminal Thousands: reserved	○	0x51B

F5-28	HDI input minimum frequency	0.00kHz	0.00~50.00kHz	●	0x51C
F5-29	HDI min frequency corresponding setting	0.00%	0.00~100.00%	●	0x51D
F5-30	HDI input max frequency	50.00kHz	0.00~50.00kHz	●	0x51E
F5-31	HDI max frequency corresponding setting	100.00%	0.00~100.00%	●	0x51F
F5-32	HDI filter time	0.100s	0.000~9.000s	●	0x520
F5-33	HDI cutoff frequency	0.010kHz	0.000~1.000kHz	●	0x521
F5-34	UP/DW terminal control mode	0	0: Frequency power-down storage 1: Frequency is not stored when power is off 2: Adjustable during operation, reset when shutdown	○	0x522
F5-35	Terminal UP / DW control frequency rate	0.50Hz/s	0.01~50.00Hz/s	●	0x523
F5-36	Reserved	---	---		0x524
F5-37	Timer time unit	0	0:Second 1:Minute 2:Hour	●	0x525
F5-38	Timer setting value	0	0~65000	●	0x526
F5-39	Reserved	---	---		0x527
F5-40	Counter input frequency	0	0~6000		0x528
F5-41	Counter max value	1000	0~65000	●	0x529
F5-42	Counter setting value	500	0~65000	●	0x52A
F5-43	Reserved	---	---		0x52B
F5-44	Output terminal polarity selection	0000	0: positive polarity 1: negative polarity Unit: DO terminal Tens: Relay 1 Hundreds: Relay 2 Thousands: Reserved		0x52C
F5-45	DO output terminal	1	Refer to attached list 5.4	●	0x52D
F5-46	Relay 1 output	4	Refer to attached list 5.4	●	0x53E
F5-47	Relay 2 output	11	Refer to attached list 5.4	●	0x53F
F5-48	DO output delay time	0.010s	0.000~6.000s	●	0x530
F5-49	Relay 1 output delay	0.010s	0.000~6.000s	●	0x531
F5-50	Relay 2 output delay	0.010s	0.000~6.000s	●	0x532
F5-51	Output frequency level 1(FDT1)	30.00Hz	0.00~Max. frequency	●	0x533
F5-52	FDT1 lag	1.00Hz	0.00~Max. frequency	●	0x534
F5-53	Output frequency level 1(FDT2)	50.00Hz	0.00~Max. frequency	●	0x535
F5-54	FDT2 lag	1.00Hz	0.00~Max. frequency	●	0x536
F5-55	Detected value reaches the given frequency	2.00Hz	0.00~50.00Hz	●	0x537

F6 Analog terminal parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F6-00	AI1 Lower limit	0.00V	0.00~10.00V	●	0x600
F6-01	AI1 Lower limit corresponding setting	0.00%	-100.00~100.00%	●	0x601

PV210 solar pump inverter user manual

F6-02	AI1 upper limit	10.00V	0.00~10.00V	●	0x602
F6-03	AI1 upper limit corresponding setting	100.00%	-100.00~100.00%	●	0x603
F6-04	AI1 filter time	0.010s	0.000~6.000s	●	0x604
F6-05	AI1 voltage / current selection	0	0: voltage 1: current	●	0x605
F6-06	AI2 Lower limit	0.00V	-10.00V~10.00V	●	0x606
F6-07	AI2 Lower limit corresponding setting	0.00%	-100.00~100.00%	●	0x607
F6-08	AI2 upper limit	10.00V	-10.00V~10.00V	●	0x608
F6-09	AI2 upper limit corresponding setting	100.00%	-100.00~100.00%	●	0x609
F6-10	AI2 filter time	0.010s	0.000~6.000s	●	0x60A
F6-11	AI2 voltage / current selection	0	0: voltage 1: current	●	0x60B
F6-12	AI1 terminal function	0	Refer to attached list 5.3	○	0x60C
F6-13	AI1 high level setting	70.00%	0.00~100.00%	●	0x60D
F6-14	AI1 low level setting	30.00%	0.00~100.00%	●	0x60E
F6-15	AI2 terminal function	0	Refer to attached list 5.3	○	0x60F
F6-16	AI2 high level setting	70.00%	0.00~100.00%	●	0x610
F6-17	AI2 low level setting	30.00%	0.00~100.00%	●	0x611
F6-18	Valid state setting when analog used as terminal	0000	0: low level 1: high level Unit: AI1 Tens: AI2	●	0x612
F6-19	Analog input curve selection	0000	0: Beeline (default) 1: curve 1 2: curve 2 Unit: AI1 Tens: AI2	●	0x613
F6-20	Reserved	---	---		0x614
F6-21	Curve 1 lower limit	0.00V	0.00~10.00V	●	0x615
F6-22	Curve 1 lower limit	0.0%	0.00~100.00%	●	0x616
F6-23	Curve 1 inflection point 1 input voltage	3.00V	0.00~10.00V	●	0x617
F6-24	Curve 1 inflection point 1 corresponding setting	30.00%	0.00~100.00%	●	0x618
F6-25	Curve 1 inflection point 2 input voltage	6.00V	0.00~10.00V	●	0x619
F6-26	Curve 1 inflection point 2 corresponding setting	60.00%	0.00~100.00%	●	0x61A
F6-27	Curve 1 upper limit	10.0V	0.00~10.00V	●	0x61B
F6-28	Curve 1 upper limit corresponding setting	100.00%	0.00~100.00%	●	0x61C
F6-29	Curve 2 lower limit	0.00V	0.00~10.00V	●	0x61D
F6-30	Curve 2 lower limit corresponding setting	0.00%	0.00~100.00%	●	0x61E
F6-31	Curve 2 inflection point 1 input voltage	3.00V	0.00~10.00V	●	0x61F
F6-32	Curve 2 inflection point 1 corresponding setting	30.00%	0.00~100.00%	●	0x620
F6-33	Curve 2 inflection point 2 input voltage	6.00V	0.00~10.00V	●	0x621

F6-34	Curve 2 inflection point 2 corresponding setting	60.00%	0.00~100.00%	●	0x622
F6-35	Curve 2 upper limit	10.00V	0.00~10.00V	●	0x623
F6-36	Curve 2 upper limit corresponding setting	100.00%	0.00~100.00%	●	0x624
F6-37	AO output signal selection	0000	Unit:AO1 0:0~10V 1:4.00~20.00mA 2:0.00~20.00mA 3:FM frequency pulse output Tens :AO2 (extended card) 0:0~10V 1:4.00~20.00mA 2:0.00~20.00mA	●	0x625
F6-38	AO1 output selection	0	0: Given frequency 1: Output frequency 2: Output current 3: Input voltage 4: Output voltage 5: Machine speed 6: Given torque 7: Output torque 8: PID given value 9: PID feedback value 10: Output power 11: Bus voltage 12: AI1 13: AI2 14: HDI input value 15,16: IGBT temperature 1,2 17: RS485 given	●	0x626
F6-39	AO2(extended card) output selection	1		●	0x627
F6-40	AO1 output gain	100.0%	25.0~200.0%	●	0x628
F6-41	AO1 analog outputsignal bias	0.0%	-10.0~10.0%	●	0x629
F6-42	AO1 output filter	0.010s	0.000~6.000s	●	0x62A
F6-43	AO2(extended card) output gain	100.0%	25.0~200.0%	●	0x62B
F6-44	AO2(extended card) analog output signal bias	0.0%	-10.0%~10.0%	●	0x62C
F6-45	AO2(extended card) output filter	0.010s	0.000~6.000s	●	0x62D
F6-46	AO1 FM frequency output lower limit	0.20kHz	0.00~100.00kHz	●	0x62E
F6-47	AO1 FM frequency output upper limit	50.00kHz	0.00~100.00kHz	●	0x62F

F7 System parameters

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
-----	----------------------	-----------------	----------------------------------	---------	---------

PV210 solar pump inverter user manual

F7-00	Parameter and key lock selections	0	0: Not locked 1: Function parameter locked 2: Function parameter and key locked (except for RUN、STOP、JOG/REV) 3: All function parameter and key locked	●	0x700
F7-01	User password	0	0~9999	●	0x701
F7-07	Keyboard JOG/REV selection	0	0: REV 1: JOG 2: Reverse	○	0x707
F7-08	STOP key setting	1	0: Non-keyboard control mode is invalid 1: Non-keyboard control mode stops according to stop mode 2: Non-keyboard control mode stop according to free stop mode	○	0x708
F7-09	UP/DOWN key selection	0011	Unit: keyboard UN/DOWN key modify selection 0: Invalid 1: Modify frequency setting by key board numbers F0-08 2: Modify PID give setting by key board numbers FA-01 Tens :power off storage selection 0: No save frequency after power off 1: Save frequency after power off Hundreds:action limit 0: Operation stop for adjusting 1: Adjusting only in operation, stop for holding 2: Adjusting in operation, stop for clearing	○	0x709
F7-10	Keyboard potentiometer lower limit	0.50V	0.00~5.00V	●	0x70A
F7-11	Corresponds to the lower limit of the keyboard	0.00	0.00~100.00%	●	0x70B
F7-12	Keyboard potentiometer upper limit	4.50V	0.00~5.00V	●	0x70C
F7-13	Keyboard potentiometer upper limit correspondence	100.00	0.00~100.00%	●	0x70D
F7-14	The display content of the first line in running state	1101	Unit and Tens: display the first group 00~63 Hundreds and Thousands: display the second group 00~63	●	0x70E
F7-15	The display content of the first line in running state	0402	Same as F7-14	●	0x70F
F7-16	The display content of the first line in stop state	1100	Same as F7-14	●	0x710
F7-17	The display content of the first line in stop state	0402	Same as F7-14	●	0x711
F7-18	The display content of the second line in running state	0402	Same as F7-14	●	0x712
F7-19	The display content of the second line in running state	1210	Same as F7-14	●	0x713
F7-20	The display content of the second line in stop state	0402	Same as F7-14	●	0x714
F7-21	The display content of the second line in stop state	1210	Same as F7-14	●	0x715

F7-22	Keyboard display item setting	0000	Unit: output frequency selection 0: Aim frequency 1: Running frequency Hundreds: power display dimension 0: Power display percentage (%) 1: Power display kilowatt (KW)	●	0x716
F7-24	Rotate speed display	100.0%	0.0~500.0%	●	0x718
F7-25	Power display coefficient	100.0%	0.0~500.0%	●	0x719

F8 Enhanced Function Parameter Group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F8-00	Jump frequency 1	0.00Hz	0.00~max frequency	●	0x800
F8-01	Jump frequency amplitude 1	0.00Hz	0.00~max frequency	●	0x801
F8-02	Jump frequency 2	0.00Hz	0.00~max frequency	●	0x802
F8-03	Jump frequency amplitude 2	0.00Hz	0.00~max frequency	●	0x803
F8-04~F8-07		Reserved			
F8-08	Swing frequency control	0	0: invalid 1: valid	●	0x808
F8-09	Swing frequency amplitude control	0	0: relative center frequency 1: Relative maximum frequency	●	0x809
F8-10	Reserved				
F8-11	Swing frequency amplitude	10.0%	0.0~100.0%	●	0x80B
F8-12	Kick frequency amplitude	10.0%	0.0~50.0%	●	0x80C
F8-13	Swing frequency ACC time	5.00s	0.00~650.00s	●	0x80D
F8-14	Swing frequency DEC time	5.00s	0.00~650.00s	●	0x80E
F8-15	Fan control	1	0: Fan runs after inverter is powered on 1: Shutdown is related to temperature, and running is running 2: The shutdown fan stops, and the operation is related to temperature	●	0x80F
F8-16	Energy consumption braking enabled	0	0: OFF 1: ON	●	0x810
F8-17	Energy consumption braking action voltage	135.0%	115.0%~150.0%	●	0x811
F8-18	Energy use brake usage	10.0%	0.0~100.0%	●	0x812
F8-19~F8-20		Reserved			

F9 Protection and Malfunction Parameter Group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
F9-00	OC suppression function	0	0: Suppression valid 1: ACC/DEC valid, constant speed invalid	○	0x900
F9-01	OC suppression point	160.0%	0.0 ~ 300.0%	●	0x901
F9-02	OC suppression gain	100.0%	0.0 ~ 500.0%	●	0x902

PV210 solar pump inverter user manual

F9-03	Current hardware protection settings	0001	Unit: CBC(cycle by cycle, limit current according to its waveform) 0: off 1: on Tens: OC protection interference suppression 0: off 1: First grade 2: Second grade Hundreds: SC protection interference suppression 0: off 1: First grade 2: Second grade Thousands: Reserved	○	0x903
F9-04～F9-05		Reserved			
F9-06	Bus overvoltage suppression function	0012	Unit: Over voltage suppression 0: Invalid 1: Valid in DEC 2: Valid both in ACC/DEC Tens: Over-excitation control 0: off 1: on Hundreds and Thousands: Reserved	○	0x906
F9-07	Bus overvoltage suppression	130.0%	110.0 ～ 150.0%	※	0x907
F9-08	Bus overvoltage suppression gain	100.0%	0.0 ～ 500.0%	●	0x908
F9-09	Bus undervoltage suppression function	0	0: Invalid 1: Valid	○	0x909
F9-10	Bus undervoltage suppression point	80.0%	60.0 ～ 90.0%	※	0x90A
F9-11	Bus undervoltage suppression gain	100.0%	0.0 ～ 500.0%	●	0x90B
F9-12	Bus undervoltage protection point	60.0%	60.0 ～ 90.0%	※	0x90C
F9-13	Reserved				0x90D
F9-14	Short-circuit detection after power on	0	0: off 1: on	○	0x90E
F9-15	Phase missing protection	0011	Unit: Output phase missing protection 0: off 1: on Tens: Input phase missing protection 0: off 1: Open Alarm 2: Open Fault(STOP VFD) Hundreds and Thousands: Reserved	●	0x90F
F9-16	Motor overload protection curve coefficient	100.0%	0.0～250.0%	●	0x910

F9-17	Load warning checkout setting	0000	Unit: checkout selection (protection 1) 0: No detection 1: detection load is too large 2: Only at constant speed detects excessive load 3: detection of insufficient load 4: Detects insufficient load only at constant speed Tens: Alarm selection 0: Alarm, continue running 1: fault protection action and free stop Hundreds: Check Out Selection (Protection 2) 0: No detection 1: detection load is too large 2: Only at constant speed detects excessive load 3: detection of insufficient load 4: Detects insufficient load only at constant speed Thousands: Alarm selection 0: Alarm, continue running 1: fault protection action and free stop	○	0x911
F9-18	Load early detection level 1	130.0%	0.0~200.0%	○	0x912
F9-19	Load warning detection time 1	5.0s	0.0~60.0s	○	0x913
F9-20	Load early detection level 2	30.0%	0.0~200.0%	○	0x914
F9-21	Load warning detection time 2	5.0s	0.0~60.0s	○	0x915
F9-22	Reserved	---			0x916
F9-23	Protection action of speed bias excess	0000	Unit: Detection selection 0: Not detected 1: Detected only at constant speed 2: Detecting Tens: Alarm selection 0: Free stop and report fault 1: Alarm and continue operation Hundreds and Thousands: Reserved	○	0x917
F9-24	Detection threshold when speed bias excess	10.0%	0.0~60.0%	○	0x918
F9-25	Detection time when speed bias excess	2.0s	0.0~60.0s	○	0x919
F9-26	Rapid protection action	0000	Unit:checkout selection 0: No detection 1: only at constant speed 2: Always detect Tens:Alarm selection 0: Free stop and report fault 1: Alarm and continue operation Hundreds and thousands: reserved	○	0x91A
F9-27	Fast detection threshold	110.0%	0.0~150.0%	○	0x91B
F9-28	Fast detection time	0.010s	0.000~2.000s	○	0x91C

F9-29~F9-36		Reserved			
F9-37	Failure self-recovery times	0	0~5	○	0x925
F9-38	Failure self-recovery interval	1.0s	0.1~100.0s	○	0x926

FA PID control parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
FA-00	PID controller given signal source	0	0: Keyboard numeric PID given 1: keyboard potentiometer given 2: AI1 given 3: AI2 4: Pulse HDI given 5: RS485 communication given 6: Optional card 7: terminal selection	●	0xA00
FA-01	Keyboard digit PID given / feedback	50.0%	0.00~100.0%	●	0xA01
FA-02	PID given changing time	1.00s	0.00~60.00s	●	0xA02
FA-03	PID controller feedback signal source	2	0: Keyboard numeric PID given 1: keyboard potentiometer given 2: AI1 given 3: AI2 4: Pulse HDI given 5: RS485 communication given 6: Optional card 7: terminal selection	●	0xA03
FA-04	Feedback signal filter time	0.010s	0.000~6.000s	●	0xA04
FA-05	Feedback signal gain	1.00	0.00~10.00	●	0xA05
FA-06	Maximum feedback signal	100.0	0~100.0	●	0xA06
FA-07	PID control selection	0100	Unit: feedback characteristic selection 0: Positive characteristic 1: negative characteristics Tens: closed-loop bypass hold output 0: Output is cleared when closed loop bypass 1: Output hold when closed loop bypass Hundreds: alignment selection 0: non-center aligned 1: center-aligned Thousands: Differential Adjustment Properties 0: Differentiate the deviation 1: Differentiate feedback	○	0xA07
FA-08	PID preset output	100.0%	0.0~100.0%	●	0xA08
FA-09	PID preset output running	0.0s	0.0~6500.0s	●	0xA09
FA-10	PID control deviation limit	0.0%	0.0~100.0%	●	0xA0A
FA-11	Proportional gain P1	0.100	0.000~8.000	●	0xA0B
FA-12	Integration time I1	1.0s	0.0~600.0s	●	0xA0C
FA-13	Differential time D1	0.000s	0.000~6.000s	●	0xA0D
FA-14	Proportional gain P2	0.100	0.000~8.000	●	0xA0E

FA-15	Integration time I2	1.0s	0.0~600.0s	●	0xA0F
FA-16	Differential time D2	0.000s	0.000~6.000s	●	0xA10
FA-17	PID Parameter switching condition	0	0: No switch 1: DI terminal switching 2: switch based on deviation	●	0xA11
FA-18	Low value of switching deviation	20.0%	0.0~100.0%	●	0xA12
FA-19	High value of switching deviation	80.0%	0.0~100.0%	●	0xA13
FA-21	Differential limit	5.0%	0.0~100.0%	●	0xA15
FA-22	PID output upper limit	100.0%	0.0~100.0%	●	0xA16
FA-23	PID output lower limit	0.0%	0.0~[FA-22]	●	0xA17
FA-24	PID output filter time	0.0s	0.000~6.000s	●	0xA18
FA-25	Feedback wire break detection time	1.0s	0.0~120.0s	●	0xA19
FA-26	Feedback wire break action selection	0	0: Continue without failure 1: Stop and report failure 2: keep running, output alarm 3: Run at current frequency and alarm	●	0xA1A
FA-27	Wire break alarm upper limit	100.0%	0.0~100.0%	●	0xA1B
FA-28	Wire break alarm lower limit	0.0%	0.0~100.0%	●	0xA1C
FA-29	Dormancy selection	0	0:OFF 1:ON	●	0xA1D
FA-30	Dormant frequency	30.00Hz	0.00~50.00Hz	●	0xA1E
FA-31	Dormant delay time	3.0S	0.0~3600.0S	●	0xA1F
FA-32	Wake-up bias	5.0%	0.0~50.0%	●	0xA20
FA-33	Wake-up delay	0.0S	0.0~60.0S	●	0xA21

Fb Fault Record Parameter Group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
Fb-00	Trouble shooting information	--	See fault message code table for details	×	0xB00
Fb-01	Fault type	--	See fault message code table for details	×	0xB01
Fb-02	Fault operating frequency	--	0.00~Max frequency	×	0xB02
Fb-03	Fault output voltage	--	0~1500V	×	0xB03
Fb-04	Fault output current	--	0.1~2000.0A	×	0xB04
Fb-05	Fault bus voltage	--	0~3000V	×	0xB05
Fb-06	Failure module temperature	--	0~100℃	×	0xB06
Fb-07	Fault inverter status	--	Unit:running direction 0: forward 1: reverse Tens:running status 0: shutdown 1: speed up 2: slowdown 3: constant speed Hundreds and thousands: reserved	×	0xB07
Fb-08	Fault input terminal status	--	See input terminal state diagram	×	0xB08
Fb-09	Fault output terminal status	--	See output terminal state diagram	×	0xB09
Fb-10	Previous failure type	--	See fault message code table for details	×	0xB0A

PV210 solar pump inverter user manual

Fb-11	Frequency of previous fault operation	--	0.00~Max frequency	×	0xB0B
Fb-12	Last fault output voltage	--	0~1500V	×	0xB0C
Fb-13	Last fault output current	--	0.1~2000.0A	×	0xB0D
Fb-14	Last faulted bus voltage	--	0~3000V	×	0xB0E
Fb-15	Last failed module	--	0~100℃	×	0xB0F
Fb-16	Status of the previous fault inverter	--	Unit:running direction 0: forward 1: reverse Tens:running status 0: shutdown 1: steady speed 2: speed up 3: slow down Hundreds and thousands: reserved	×	0xB10
Fb-17	Last fault input terminal status	--	See input terminal state diagram	×	0xB11
Fb-18	Last fault output terminal status	--	See output terminal state diagram	×	0xB12
Fb-19	First two failure types	--	See fault message code table for details	×	0xB13
Fb-20	First three failure types	--	See fault message code table for details	×	0xB14

FC Multi-speed, PLC function parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
FC-00	Multi-speed frequency 1	10.00Hz	0.00~Max frequency	●	0xC00
FC-01	Multi-speed frequency 2	20.00Hz	0.00~Max frequency	●	0xC01
FC-02	Multi-speed frequency 3	30.00Hz	0.00~Max frequency	●	0xC02
FC-03	Multi-speed frequency 4	40.00Hz	0.00~Max frequency	●	0xC03
FC-04	Multi-speed frequency 5	50.00Hz	0.00~Max frequency	●	0xC04
FC-05	Multi-speed frequency 6	40.00Hz	0.00~Max frequency	●	0xC05
FC-06	Multi-speed frequency 7	30.00Hz	0.00~Max frequency	●	0xC06
FC-07	Multi-speed frequency 8	20.00Hz	0.00~Max frequency	●	0xC07
FC-08	Multi-speed frequency 9	10.00Hz	0.00~Max frequency	●	0xC08
FC-09	Multi-speed frequency 10	20.00Hz	0.00~Max frequency	●	0xC09
FC-10	Multi-speed frequency 11	30.00Hz	0.00~Max frequency	●	0xC0A
FC-11	Multi-speed frequency 12	40.00Hz	0.00~Max frequency	●	0xC0B
FC-12	Multi-speed frequency 13	50.00Hz	0.00~Max frequency	●	0xC0C
FC-13	Multi-speed frequency 14	40.00Hz	0.00~Max frequency	●	0xC0D
FC-14	Multi-speed frequency 15	30.00Hz	0.00~Max frequency	●	0xC0E
FC-15	Multi-speed frequency running mode selection	0000	Unit: cycle mode 0: Stop after single cycle 1: Continuous cycles 2: Keep final value after single cycle Tens: Time unit 0: second 1: minute 2:hour Hundreds: Power down memory 0: Not save 1: save Thousands: Start mode 0: Restart from the 1st stage 1: Restart from the stop stage	●	0xC0F

			2: Continue running from the time when stop		
FC-16	Multi-speed 1 running time	10.0	0.0～6500.0(s/m/h)	●	0xC10
FC-17	Multi-speed2running time	10.0	0.0～6500.0(s/m/h)	●	0xC11
FC-18	Multi-speed 3running time	10.0	0.0～6500.0(s/m/h)	●	0xC12
FC-19	Multi-speed4running time	10.0	0.0～6500.0(s/m/h)	●	0xC13
FC-20	Multi-speed5running time	10.0	0.0～6500.0(s/m/h)	●	0xC14
FC-21	Multi-speed6running time	10.0	0.0～6500.0(s/m/h)	●	0xC15
FC-22	Multi-speed7running time	10.0	0.0～6500.0(s/m/h)	●	0xC16
FC-23	Multi-speed 8running time	10.0	0.0～6500.0(s/m/h)	●	0xC17
FC-24	Multi-speed9running time	10.0	0.0～6500.0(s/m/h)	●	0xC18
FC-25	Multi-speed10running time	10.0	0.0～6500.0(s/m/h)	●	0xC19
FC-26	Multi-speed 11running time	10.0	0.0～6500.0(s/m/h)	●	0xC1A
FC-27	Multi-speed12running time	10.0	0.0～6500.0(s/m/h)	●	0xC1B
FC-28	Multi-speed 13running time	10.0	0.0～6500.0(s/m/h)	●	0xC1C
FC-29	Multi-speed14running time	10.0	0.0～6500.0(s/m/h)	●	0xC1D
FC-30	Multi-speed15running time	10.0	0.0～6500.0(s/m/h)	●	0xC1E
FC-31	Multi- speed frequency 1-15 direction and ACC/DEC time	0000	Unit :the running direction of this paragraph 0: forward 1: reverse Tens : ACC / DEC time of this speed 0: acceleration / deceleration time 0 1: acceleration / deceleration time 1 2: acceleration / deceleration time 2 3: acceleration / deceleration time 3 Hundreds and thousands : Reserved	●	0xC1F
FC-32		0000		●	0xC20
FC-33		0000		●	0xC21
FC-34		0000		●	0xC22
FC-35		0000		●	0xC23
FC-36		0000		●	0xC24
FC-37		0000		●	0xC25
FC-38		0000		●	0xC26
FC-39		0000		●	0xC27
FC-40		0000		●	0xC28
FC-41		0000		●	0xC29
FC-42		0000		●	0xC2A
FC-43		0000		●	0xC2B
FC-44		0000		●	0xC2C
FC-45		0000		●	0xC2D
FC-46～FC-48		Reserved			

Fd Communication control function parameter group

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
Fd-00	Master-slave machine selection	0	0: Slave machine 1: Main machine	○	0xD00
Fd-01	485 communication address	1	1~247	○	0xD01
Fd-02	485 communication baud rate selection	3	0:1200 bps 1:2400 bps 2:4800 bps 3:9600 bps 4:19200 bps 5:38400 bps	○	0xD02

Fd-03	Modbus data format	0	0:(N,8,1) 1:(E,8,1) 2:(O,8,1) 3:(N,8,2) 4:(E,8,2) 5:(O,8,2)	○	0xD03
Fd-04	Communication ratio setting	1.00	0.00~5.00	●	0xD04
Fd-05	Modbus communication answer delay	0ms	0~500ms	●	0xD05
Fd-06	Communication timeout failure time	1.0s	0.1~100.0s	●	0xD06
Fd-07	Modbus communication fault action mode selection	0	0: No detection 1: Alarm and free stop 2: Alarm and continue running 3: Forced stop	●	0xD07
Fd-08	Modbus Responds dispose	0	0: Have response 1: No response	●	0xD08
Fd-09	Main machine sending selection	0031	Unit: the first group of transmission frame selection 0: Invalid 1: Main machine run command 2: Main machine given frequency 3: Main machine output frequency 4: Main machine upper limit frequency 5: Main machine given torque 6: Main machine output torque 7, 8: Reserved 9: Main machine given PID A: Main machine feedback PID Tens: the second group transmitting frame selection Hundreds: the third group transmitting frame selection Thousands: the fourth group transmitting frame selection same as above	●	0xD09
Fd-10	RS485 Communication port configuration	0	0: Modbus communication 1: serial port communication	●	0xD0A

FE Torque Control Parameters

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
FE-00	Torque/Speed control	0	0:Speed control 1:Torque control Torque/Speed control	●	0xE00
FE-01	Torque given channels selection	0	0: Keyboard number setting 1: Potentiometer of keyboard given 2: Voltage/Current analog AI1 given 3: Voltage/Current analog AI2 given 4: Terminal pulse HDI given 5: RS485 communication given	●	0xE01
FE-02	Torque keyboard number setting	0.0%	0~100.0%	●	0xE02
FE-03	Torque input lower limit	0.00%	0.00~100.00%	●	0xE03

FE-04	Lower limit corresponding setting	0.00%	-200.00~200.00%	●	0xE04
FE-05	Torque input upper limit	100.00%	0.00~100.00%	●	0xE05
FE-06	Upper limit corresponding setting	100.00%	-200.00~200.00%	●	0xE06
FE-07	Given first-order filter time	0.100s	0.000~6.000s	●	0xE07
FE-08	Output torque upper limit	150.0%	0~200.0%	●	0xE08
FE-09	Output torque lower limit	0%	0~200.0%	●	0xE09
FE-10	Torque control FWD speed limit selection	0	0:function code FE-12setting 1:potentiometer of keyboard×FE-12; 2:AI1×FE-12; 3:AI2×FE-12; 4:HDI×FE-12; 5:RS485 communication given×FE-12	●	0xE0A
FE-11	Torque control REV speed limit selection	0	0:function code FE-13setting 1:potentiometer of keyboard×FE-13; 2:AI1×FE-13; 3:AI2×FE-13; 4:HDI×FE-13; 5:RS485 communication given×FE-13	●	0xE0B
FE-12	Torque control FWD max speed limit	100.0%	0.0~100.0%	●	0xE0C
FE-13	Torque control REV max speed limit	100.0%	0.0 ~ 100.0%	●	0xE0D

A0 Photovoltaic Pump Special Parameters

NO.	Function description	Factory default	Range of settings and definition	Feature	Address
A0-00	Photovoltaic water pump mode	0002	Unit: Mode selection 0:Variable frequency control mode 1:CVT mode for solar 2:MPPT mode Tens: Motor selection 0: Three phase motor 1: Single phase motor Hundreds: Pump clean 0:Invalid 1:valid Thousands: Reserved	○	
A0-01	CVT Target voltage	81.0%	0.0%~100.0%	●	
A0-02	VOC Voltage	read-only	0.0V~999.9V		
A0-03	MPPT Voltage upper limit	100.0%	20.0%~200.0%	●	
A0-04	MPPT Voltage Low Limit	50.0%	20.0%~200.0%	●	
A0-05	MPPT Search interval	1.0s	0.1s~30.0s	●	
A0-06	MPPT Adjust gain	100	0~9999	●	
A0-07	Frequency adjusting gain	10.0%(AM) 40.0%(PM)	0.1%~500.0%	●	

PV210 solar pump inverter user manual

A0-08	Photovoltaic water pump function selection 1	1100H	0: Invalid ; 1: valid Unit: Constant torque frequency limit selection Tens: Reserved Hundreds: Voltage surge updates VOC voltage Thousands: Fast frequency falling function	●	
A0-09	Constant torque frequency limiting factor	100.0%	80.0%~150.0%	●	
A0-10	Voltage surge threshold	5.0%	0.0%~20.0%	●	
A0-11	Fast frequency reduction threshold	5.0%	3.0%~15.0%	●	
A0-12	Fast frequency reduction gain	2	0~20	●	
A0-13	Frequency adjusted filtering time	0.002	0.001~2.000S	●	
A0-14	Sleep voltage threshold	250V	0~1000V	●	
A0-15	Sleep recovery voltage	350V	0~1000V	●	
A0-16	Waiting time of sleep and shutdown	60.0s	0.0~3000.0s	●	
A0-17	Detection of low frequency protection frequency	10.00Hz	0.00~300.00Hz	●	
A0-18	Detection time of low frequency protection	10.0s	0.0~3000.0s	●	
A0-19	Automatic recovery time of low frequency protection	10.0s	0.0~3000.0s	●	
A0-20	Detection current of dry protection	0.0A	0.0~999.9A	●	
A0-21	Detection time of drying protection	10.0s	0.0~3000.0s	●	
A0-22	Automatic recovery time of dry protection	60.0s	0.0~3000.0s	●	
A0-23	Detection current of over current protection	0.0A	0.0A~999.9A	●	
A0-24	Detection time of Over current protection	10.0s	0.0s~3000.0s	●	
A0-25	Automatic recovery time of over current protection	60.0s	0.0s~3000.0s	●	
A0-26	Minimum power protection value	0.00kw	0.00kw~650.00kw	●	
A0-27	Detection time of minimum power protection	10.0s	0.0s~3000.0s	●	
A0-28	Automatic recovery time of minimum power protection	60.0s	0.0s~3000.0s	●	

A0-29	Alarm recovery mode	0000H	0:Autorecovery 1:Manual recovery Unit: Low frequency protection Tens: Dry protection Hundreds: Over current and overload protection Thousands: Minimum power protection	●	
A0-30	Detection time of full water protection	10.0s	0.0s~3000.0s	●	
A0-31	Exit time of full water protection	10.0s	0.0s~3000.0s	●	
A0-32	Accessibility function	0110H	Unit: 0: The upper limit is limited by the given frequency 1: The upper limit frequency is limited by the rated frequency of the motor Tens: 0: The min Hz is 0; 1: The lower limit frequency is minimum to 1/4 of the motor rated frequency		
A0-33	DC current correction bias	0.01A	0.00A~99.99A	●	
A0-34	DC current correction ratio	100.0%	0.0%~999.9%	●	
A0-35	Power curve 0	0.50kw	0.00kw~99.99kw	●	
A0-36	Power curve 1	1.00kw	0.00kw~99.99kw	●	
A0-37	Power curve 2	1.50kw	0.00kw~99.99kw	●	
A0-38	Power curve 3	2.00kw	0.00kw~99.99kw	●	
A0-39	Power curve 4	2.50kw	0.00kw~99.99kw	●	
A0-40	Flow curve 0	0.0m³/h	0.0m³/h~999.9m³/h	●	
A0-41	Flow curve 1	5.0 m³/h	0.0 m³/h~999.9 m³/h	●	
A0-42	Flow curve 2	10.0m³/h	0.0 m³/h~999.9m³/h	●	
A0-43	Flow curve 3	15.0m³/h	0.0 m³/h~999.9m³/h	●	
A0-44	Flow curve 4	20.0m³/h	0.0 m³/h~999.9m³/h	●	
A0-45	Flow calculation correction bias	0.0m³	0.0m³~999.9m³	●	
A0-46	Flow correction gain	100.0%	0.0%~999.9%	●	
A0-47	Clearing cycle of daily flow / daily electricity	7.0h	0.0h~24.0h	●	
A0-48	Initiating frequency of dry run protection	0.00Hz	0.00Hz~150.00Hz	●	
A0-49	Reserved	---	---	●	
A0-50	Reserved	---	---	●	
A0-51	Reserved	---	---	●	
A0-52	Water tank fulling Level detecting method	0	0: Single point detect 1: Two points detect	●	

PV210 solar pump inverter user manual

A0-53	Pump cleaning setting frequency	25.00Hz	0.00Hz~300.00Hz	●	
A0-54	FWD cleaning time	60	0s~3000s	●	
A0-55	REV cleaning time	60	0s~3000s	●	
A0-56	Recycle times of cleaning	10	0~100h	●	

5.3 Terminal input function selection

0: No function	1: FWD	2: REV	3: 3-line running(DI)
4: FWD JOG	5: REV JOG	6: Free stop	7: Emergency stop
8: Fault reset	9: External Fault input	10: Frequency UP	11: Frequency DW
12: UP/DW clear	13: Channel A to Channel B	14: Frequency channel switched to A	15: Frequency channel switched to B
16: Multi-speed terminal 1	17: Multi-speed terminal2	18: Multi-speed terminal3	19: Multi-speed terminal4
20: PID control cancel	21: PID control pause	22: PID trait switch	23: PID gain switch
24: PID given switch 1	25: PID given switch2	26: PID given switch3	27: PID feedback switch1
28: PID feedback switch2	29: PID feedback switch3	30: PLC pause	31: PLC restart
32: ACC/DEC time selection terminal 1	33: ACC/DEC time selection terminal 2	34: ACC/DEC pause	35: Swing frequency input
36: Swing frequency pause	37: Swing frequency reset	38: Speed torque control switch	39: Run pause
40: Timer trigger terminal	41: Timer clear terminal	42: Counter input terminal	43: Counter clear terminal
44: DC braking command	45: Pre-excitation command terminal	46: Command channel switch to keyboard	47: Command channel switch to terminal
48: Command channel switch to RS485	49: Command channel switch to expansion card	50: Operation banned	51: FWD banned
52: REV banned	53: Water-full detect alarm 1	54: Water-full detect alarm 2	55: Hybrid mode
56: Dry running input	57: MPPT tracking stop	Reserved	

5.4 Terminal output function selection

0: No output	1: Inverter running	2: REV running	3: FWD running
4: Fault warning 1,enable output including fault reset auto period	5: Fault trip alarm 2(no alarm when fault self-recovery)	6: External fault stop	7: External fault stop Under voltage
8: Ready for running	9: Output frequency level detection 1(FDT1)	10: Output frequency level detection 2(FDT2)	11: Reach given frequency
12: 0 speed running	13: Reach upper limit frequency	14: Reach lower frequency limit	15: Program run cycle completed
16: Program running segment completed	17: PID feedback exceeds upper limit	18: PID feedback under lower limit	19: PID feedback sensor wires break
20: Timer time arrived	21: Counter reaching max value	22: Counter reach set value	23: Braking
24: PG feedback wire break	25: Emergency stopping	26: Load pre-alarm output 1	27: Load pre-alarm output 2
28: RS485 given	Reserved		

5.5 Monitoring code

Function code number	Function name	Unit and definition	Address
U1-00	Given frequency	0.01Hz	2100H
U1-01	Output frequency	0.01Hz	2101H
U1-02	Output current	0.1A	2102H
U1-03	DC voltage of PV arrays	0.1V	2103H
U1-04	Output voltage	0.1V	2104H
U1-05	Motor(pump)speed	1RPM	2105H
U1-06	Input voltage	0.1V	2106H
U1-07	Output power	0.1%	2107H
U1-08	Given torque	0.1%	2108H
U1-09	Output torque	0.1%	2109H
U1-10	PID given value	0.1%	210AH
U1-11	PID feedback value	0.1%	210BH
U1-12	Module temperature 1	0.1℃	210CH
U1-13	Module temperature 2	0.1℃	210DH
U1-14	Input terminal DI on state	See input terminal diagram	210EH
U1-15	Output terminal DO on state	See output terminal diagram	210FH
U1-16	Input value of analog signal AI1	0.001V	2110H
U1-17	Input value of analog signal AI2	0.001V/0.001mA	2111H
U1-18	Pulse signal HDI input value	0.001kHz	2112H
U1-19	Analog output AO1	0.01V	2113H
U1-20	Analog output AO2	0.01V/0.01mA/0.01kHz	2114H
U1-21	Counter count values		2115H
U1-22	Running time of this time	0.1H	2116H
U1-23	Cumulative running time	H	2117H
U1-24	Power factor Angle	1°	2118H
U1-25	Power grade of the Inverter	kW	2119H
U1-26	Rated voltage of the Inverter	V	211AH
U1-27	Rated current of the Inverter	A	211BH
U1-28	Software version		211CH

U1-29	Inverter Working status	0:Stop 1:Running 2:Sleep 3:Low speed protection 4:Dry run protection 5:Overcurrent protection 6:Minimum power protection	211DH
-------	-------------------------	--	-------

5.6 Fault code table

Communication code	Fault display	Fault name	Troubleshooting	Solution
1	E. SC1	System abnormal	<ul style="list-style-type: none"> ● The acceleration time is set too short; ● The output of the inverter is short-circuited between phases or to ground; ● The module is damaged; ● Electromagnetic interference. 	<ul style="list-style-type: none"> ● Prolong the acceleration time appropriately; ● Check peripheral equipment and restart after troubleshooting; ● Seek technical support from manufacturers; ● Check the wiring, grounding, and shielding.
4	E.oC1	ACC over current	<ul style="list-style-type: none"> ● The acceleration time is set too short; ● Start the rotating motor; ● The capacity of the inverter is too small. 	<ul style="list-style-type: none"> ● Prolong the acceleration time appropriately; ● The motor stops or restarts after speed tracking; ● Use inverters with matching capacity levels
5	E.oC2	DEC over current	<ul style="list-style-type: none"> ● The deceleration time is set too short; ● Large potential energy load or load inertia; ● The capacity of the inverter is too small. 	<ul style="list-style-type: none"> ● Prolong the deceleration time appropriately; ● External braking resistor or braking unit; ● Select the inverter with matching capacity level.
6	E.oC3	Overcurrent at constant speed	<ul style="list-style-type: none"> ● Sudden load change; ● The grid voltage is low. 	<ul style="list-style-type: none"> ● Check the change of load and eliminate it; ● Check the input power and remove the fault.
7	E.oU1	ACC over voltage	<ul style="list-style-type: none"> ● Power supply voltage fluctuation exceeds the limit; ● Start the rotating motor. 	<ul style="list-style-type: none"> ● Detect the grid voltage and remove the fault; ● The motor stops or restarts after speed tracking;
8	E.oU2	DEC over voltage	<ul style="list-style-type: none"> ● The DEC time is set too short; ● Load potential energy or inertia is too large; ● The power supply voltage has exceeded the limit. 	<ul style="list-style-type: none"> ● Prolong the DEC time appropriately; ● Increase the capacity of the inverter or add a braking unit; ● Check the input power and remove the fault.

9	E.oU3	Overvoltage at constant speed	<ul style="list-style-type: none"> ● The power supply voltage has exceeded the limit. 	<ul style="list-style-type: none"> ● Check the input power and remove the fault.
11	E.LU2	Under voltage when running	<ul style="list-style-type: none"> ● The power supply voltage is too low; ● There is a large inrush current in the power grid; ● The internal DC main contactor is not closed. 	<ul style="list-style-type: none"> ● Check the input power and remove the fault; ● Improve the power supply system; ● Seek technical support from the manufacturer.
12	E.oL1	Motor overload	<ul style="list-style-type: none"> ● The grid voltage is low; ● Motor overload protection coefficient is not set properly; ● The motor is stalled or the load is too heavy; ● Low speed running. 	<ul style="list-style-type: none"> ● Check the input power; ● Use inverters with matching capacity levels; ● For long-term low-speed operation, select a dedicated motor. ● Speed regulation overload coefficient
13	E.oL2	Inverter overload	<ul style="list-style-type: none"> ● The load is too heavy ● The acceleration time is set too short; ● Start the rotating motor; 	<ul style="list-style-type: none"> ● Use inverters with matching capacity levels; ● Prolong the acceleration time appropriately; ● The motor stops or restarts after speed tracking;
14	E.iLF	Input phase loss	<ul style="list-style-type: none"> ● The input power is abnormal; ● The internal circuit is abnormal; 	<ul style="list-style-type: none"> ● Check the input power; ● Seek technical support from the manufacturer.
15	E.oLF	Output phase loss	<ul style="list-style-type: none"> ● The three-phase output of the inverter is lacking. 	<ul style="list-style-type: none"> ● Check the output voltage, current and motor wiring;
16	E.oH1	Motor overheat	<ul style="list-style-type: none"> ● The ambient temperature is too high; ● The air duct is blocked or the fan is abnormal; ● The temperature detection circuit is faulty. 	<ul style="list-style-type: none"> ● Make the operating environment of the inverter meet the specifications; ● Drain the air duct or replace the fan of the same model; ● Seek technical support from the manufacturer.
17	E.oH2	Inverter overheat	<ul style="list-style-type: none"> ● The ambient temperature is too high; ● The air duct is blocked or the fan is abnormal; ● The temperature detection circuit is faulty. 	<ul style="list-style-type: none"> ● Make the operating environment of the inverter meet the specifications; ● Drain the air duct or replace the fan of the same model; ● Seek technical support from the manufacturer.
18	E. EF	External fault	<ul style="list-style-type: none"> ● External equipment failure protection action. 	<ul style="list-style-type: none"> ● Check external equipment.
19	E.SE1	RS485 communication fault	<ul style="list-style-type: none"> ● The baud rate is set incorrectly; ● Communication connection is broken; ● The communication format does not match the host computer. 	<ul style="list-style-type: none"> ● Set the matching baud rate; ● Check communication connections; ● Set the matching communication format.

20	E.HAL	Current detection fault	<ul style="list-style-type: none"> ● Detection circuit failure; ● Motor phase imbalance. 	<ul style="list-style-type: none"> ● Seek technical support; ● Check the motor and wiring.
21	E.AT1	Motor static self-learning fault	<ul style="list-style-type: none"> ● Motor detection timeout; ● Start static detection while the motor is rotating; ● The difference between the capacity of the motor and the inverter is too large; ● The motor parameters are set incorrectly. 	<ul style="list-style-type: none"> ● Check the motor wiring; ● Test after the motor stops steady; ● Replace the inverter model; ● Reset according to the motor nameplate.
26	E.EEP	Storage fault	<ul style="list-style-type: none"> ● Electromagnetic interference during storage; ● EEPROM is damaged. 	<ul style="list-style-type: none"> ● Re-enter and save; ● Seek technical support from the manufacturer.
23	E.PID	PID feedback fault	<ul style="list-style-type: none"> ● PID feedback disconnect alarm upper limit ● PID feedback disconnection alarm lower limit ● The feedback sensor is faulty or badly wired 	<ul style="list-style-type: none"> ● Check the sensor status ● Correct wiring ● Confirm the setting values of FA-27 and FA-28
40	E.Gnd	Ground short circuit fault	<ul style="list-style-type: none"> ● The motor short circuit to ground 	<ul style="list-style-type: none"> ● Check the UVW of inverter is connected to the ground
28	E. PG	PG card connection fault	<ul style="list-style-type: none"> ● PG card connect the inverter fault 	<ul style="list-style-type: none"> ● check the PG wiring
10	E.OU4	Over voltage at stop	<ul style="list-style-type: none"> ● The power supply voltage has exceeded the limit. 	<ul style="list-style-type: none"> ● Check the input power and remove the fault. ● Seek technical support from the manufacturer.
22	E.AT2	Motor dynamic self-learning fault	<ul style="list-style-type: none"> ● Start detection while the motor is rotating; ● Motor with load detection; ● Motor detection timeout; ● The difference between the capacity of the motor and the inverter is too large; ● The motor parameters are set incorrectly. 	<ul style="list-style-type: none"> ● Test after the motor stops steady; ● Disconnect the motor load and re-test; ● Check the motor wiring; ● Replace the inverter model; ● Reset according to the motor nameplate.
34	E.IAE	Learning fault of Initial position angle	<ul style="list-style-type: none"> ● The parameters set fault; ● Detection circuit fault; 	<ul style="list-style-type: none"> ● Replacement of inverter type; ● Reset according to motor nameplate. ● Seek technical support from the manufacturer.
36	E.DEV	Speed deviation excess	<ul style="list-style-type: none"> ● The Speed over the max frequency. ● Detection circuit fault; 	<ul style="list-style-type: none"> ● Change the Max frequency and Upper frequency. ● Seek technical support from the manufacturer.

37	E.SPD	Stall protection	<ul style="list-style-type: none"> ● Inverter over voltage; ● Detection circuit fault; 	<ul style="list-style-type: none"> ● Change the over voltage set. ● Seek technical support from the manufacturer.
30	E.LD1	Load protection 1	<ul style="list-style-type: none"> ● The motor is stalled over the set value. ● Detection circuit fault; 	<ul style="list-style-type: none"> ● Change the set value. ● Seek technical support from the manufacturer.
31	E.LD2	Load protection 2	<ul style="list-style-type: none"> ● The motor is stalled over the set value. ● Detection circuit failure; 	<ul style="list-style-type: none"> ● Change the set value. ● Seek technical support from the manufacturer.
33	E.LOC	CPU verification fault	<ul style="list-style-type: none"> ● CPU is Locked. 	<ul style="list-style-type: none"> ● Seek technical support from the manufacturer.
35	E.PST	Synchronous motor out-of step	<ul style="list-style-type: none"> ● The motor is stalled or the load is too heavy; ● Detection circuit failure; 	<ul style="list-style-type: none"> ● Change the Power of inverter; ● Seek technical support from the manufacturer.

Alarm code table

Communication code	Alarm display	Alarm name	Communication code	Alarm display	Alarm name
64	A.PID	PID feedback wires brake alarm	71	A.LoC	CPU Locked alarm
65	A.LD1	Load protection alarm 1	72	A.SLP	Sleep mode alarm
66	A.LD2	Load protection alarm 1	73	A.LFr	Low frequency alarm
67	A.DEF	Speed deviation excess alarm	74	A.LLd	Dry running alarm
68	A.SPD	Stall protection alarm	75	A.OLd	Over current alarm
69	A.SE	RS485 Communication alarm	76	A.LPr	Minimum power alarm
70	A.oLF	Output phase loss alarm	77	A.FuL	Water full alarm

Chapter 6 Regular Inspection and Maintenance

6.1 Inspection

Frequency inverter is composed by semi-conductive components, passive electronic component and motive component. All of these components have useful life. Even under normal working environment, some of the components cannot work after the life time. To avoid malfunction, daily checking, periodic overhaul, component changing and other maintenance should be carried out to prevent.

●Daily checking: To avoid machine damage and to prolong life time, please check the following items every day.

Check item	Check content	Standard of criterion
Input and output voltage	Check whether the power supply voltage meets the requirements and whether there is phase failure	Refer to the requirements of the name plate
Operating environment	Confirm whether the installation environment meets the requirements	Identify the source and deal with it properly
Cooling system	Working condition of cooling fan of frequency converter	There is no dirt and debris blocking the air duct
Motor	Check if there is abnormal vibration or noise	Whether there is abnormal heating, abnormal noise and vibration
Load condition	Whether the output current of frequency converter is higher than the rated value of motor or frequency converter and lasts for a certain time	Confirm whether there is overload and whether the inverter selection is correct

●Periodic inspection:According to the operating environment and working conditions, the frequency converter shall be inspected regularly every 3-6 months.

Check item	Check content	Strategy adopted
Motor	<ul style="list-style-type: none"> ● Insulation resistance inspection; ● Check if there is abnormal vibration or noise. 	<ul style="list-style-type: none"> ● Tighten machine and electric connection and lubricate the machine components.
Electric connection	<ul style="list-style-type: none"> ● Whether there is any discoloration of the wires and connection parts, whether the insulation layer is damaged, cracked, discolored, and aged; ● Whether the connection terminals are worn, damaged, or loose; 	<ul style="list-style-type: none"> ● Replace damaged wires; ● Tighten loose terminals and replace damaged terminals; ● Measure the ground resistance and tighten the corresponding ground terminal.
Mechanical connection	<ul style="list-style-type: none"> ● Whether there is abnormal vibration and noise, and whether there is loosening. 	<ul style="list-style-type: none"> ● Tighten, lubricate, and replace defective parts.
semi-conductive component	<ul style="list-style-type: none"> ● Whether it is stained with garbage and dust; ● Whether there is a noticeable change in appearance. 	<ul style="list-style-type: none"> ● Clean operating environment; ● Replace damaged parts.
Electrolytic capacitor	<ul style="list-style-type: none"> ● Check for leaks, discoloration, cracks, and exposed, swollen, cracked, or leaking safety valves. 	<ul style="list-style-type: none"> ● Replace damaged parts.

Check item	Check content	Strategy adopted
PCB	<ul style="list-style-type: none"> ● Check if there is any odor, discoloration, severe rust, and whether the connector is correct and reliable. 	<ul style="list-style-type: none"> ● Fastening connection ● Clean the printed circuit board; ● Replace damaged printed circuit boards;
Cooling system	<ul style="list-style-type: none"> ● Whether the cooling fan is damaged or blocked; ● Whether the heat sink is stained with garbage, dust, or dirt; ● Whether the air intake or exhaust is blocked or contaminated with foreign objects. 	<ul style="list-style-type: none"> ● Clean operating environment; ● Replace damaged parts.
Keyboard	<ul style="list-style-type: none"> ● Whether it is damaged. Check whether display is complete. 	<ul style="list-style-type: none"> ● Change damaged component

Attention:

Do not perform related operations with the power on, otherwise there is a danger of death due to electric shock. When carrying out related work, please cut off the power and confirm that the DC voltage of the main circuit has dropped to a safe level. Wait 5 minutes before carrying out related work.

- Component replacement: Different kinds of parts have different service life. The service life of parts is closely related to the service environment and maintenance condition. Cooling fan and electrolytic capacitor are vulnerable parts. Carry out daily inspection according to the table below. If there is any abnormality, please replace it in time.

Part name	life cycle	Cause of damage
Fan	2~3 years	Bearing wear and blade aging
Electrolytic capacitor	4~5 years	The environment temperature is high and the electrolyte volatilizes

The replacement of other components requires very strict maintenance technology and product familiarity, and after replacement, it must be strictly tested before it can be used. Therefore, it is not recommended that users replace other internal components by themselves. If it really needs to be replaced, please contact the agent where you purchased the product or our sales department.

6.2 Product storage

After purchasing the frequency converter, the temporary storage and long-term storage must pay attention to:

- When storing, try to put them into the packing box of our company according to the original package;
- The long-term storage will lead to the deterioration of the electrolytic capacitor. It must be ensured that the electrolytic capacitor is powered on once within 2 years for at least 5 hours, and the input voltage must be slowly raised to the rated value with a voltage regulator.

Chapter 7 Operation Guidance

7.1 Asynchronous Motor Pump Drive Operation Guidance

1) Wiring:

Confirmed the solar pump drive if mating with motor.

Correctly connecting “+”“-” of solar panel to corresponding “PV+”“PV-” pole of inverter wiring terminals. Otherwise it will cause inverter damage.

Connect motor wire and ground wire to corresponding U, V, W, E terminals.

2). Parameters setting and trial run:

Set F0-01 to 0, F0-02 for 1, and F0-09, F0-11, F0-14, F0-15 parameters setting according to application site.

Set motor(pump) parameters according to nameplate of pump. Set solar pump MPPT mode A0-00 for 1 or 2.

Run the inverter, and confirm the motor running direction.

3) Common problems and solutions

a, Q: Well-lit conditions, the pump is running, but the water is very small.

A: Check if the pump motor direction is reversed.

b, Q: Well-lit conditions, the drive is in standby mode 0.00Hz.

A: Check U1-29, observe what protection status is the drive in currently, check whether the parameters set is reasonable.

c, Q: DC current is incorrectly displayed.

A: Adjust A0-33, A0-34 for calibration.

d, Q: Well-lit conditions, frequency severe beating during operation.

A: Reasonably adjust A0-07 value, the adjustment is recommended to be in the vicinity of the default, too big or too small will cause frequency oscillation.

7.2 Synchronous Motor Pump Drive Operation Guidance

1) Wiring:

Confirm if the solar pump drive matches with the motor.

Connecting “+”“-” of solar panel to corresponding “PV+”“PV-” pole of inverter wiring terminals. Otherwise it will cause inverter damage.

Connect motor wire and ground wire to corresponding U, V, W, E terminals.

2) Parameters setting and trial run:

a. Set F0-01 to 3, F0-02 for 1, and F0-09, F0-11, F0-14, F0-15 can be set according to demand.

b. Set motor (pump) parameters according to nameplate of pump. Then Set F2-20 for 1, the keypad will show “Tune”, press RUN to start motor auto tuning. This process takes about three minutes;

Note:

1. If you can disconnect the motor and load, self-learning would be better;

2. The self-learning need to be done with enough sunshine and when the solar panels can provide enough energy.
- c. Set solar pump MPPT mode A0-00 for 1 or 2.
- d. Run the inverter, and confirm the motor running direction.

3) Common problems and solutions

- a, Q: Well-lit conditions, the pump is running, but the water is very small.

A: Check if the pump motor direction is reversed.

- b, Q: Well-lit conditions, the drive is in standby mode 0.00Hz.

A: Check U1-29, observe what protection status is the drive in currently, check whether the parameters set is reasonable.

- c, Q: DC current is incorrectly displayed.

A: Adjust A0-33, A0-34 for calibration.

- d, Q: Well-lit conditions, frequency severe beating during operation.

A: Reasonably adjust A0-07 value, the adjustment is recommended to be in the vicinity of the default, too big or too small will cause frequency oscillation.

7.3 Introduction of photovoltaic water pump function

A. Sleep Function

During the photovoltaic pump operation, the inverter will go into sleep state when the DC voltage provided by solar panels is lower than A0-14 (sleep voltage threshold) due to objective factors, while the keyboard warning "A.SLP"; when DC voltage provided by solar panels rises back to A0-15 (sleep recovery voltage) point, start timing and after A0-16 (sleep shutdown waiting time), the drive starts running.

B. Low-frequency Protection Function

During the operation of the photovoltaic pump, for some reason, the output frequency is lower than A0-17 (low frequency detection frequency), and after A0-18 (under frequency detection time) time, enters into the standby protection state, while the keyboard warning "A.LFr"; after entering into the standby protection state and after A0-19 (frequency protection automatic recovery) time, automatically resume to running state.

C. Dry Run Protection

During the operation of the photovoltaic pump, for some reason, the output current is less than A0-20 (dry protection current detection), and after A0-21 (dry protection detection time) time, enters into standby protection state, while the keyboard warning "A.LLd"; after entering into the standby protection state and after A0-22 (dry protection automatic recovery) time, automatically resume to running state.

D. Over-current Protection

During the operation of the photovoltaic pump, for some reason, the output current is greater than A0-23 (over current point setting), and after A0-24 (over current protection detect time) time, enters into standby protection state, while the keyboard warning "A.oLd "; after entering into the standby protection state and after A0-25 (over current protection auto recovery) time, automatically resume to running state.

E. Minimum Power Protection

During the operation of the photovoltaic pump, for some reason, the output power is less than A0-26(minimum power protection value), and after A0-27 (minimum power protection detection time) time, enters into standby protection state, while the keyboard warning "A.LPr"; after entering into the standby protection state and after A0-28 (minimum power automatic recovery)time, automatically resume to running state.

F. Full Water Protection

Detect the water full alarm and low water level through two DI terminals, realizing automatic water level control. Where in A0-30 is the water overflow protection detection time and A0-31 is full water protection exit time, DI3 terminal is photovoltaic water full detection alarm signal input, DI4 terminal is photovoltaic water full detection alarm reset input,the warning signal is shown as "A.Ful".

G. Alarm Recovery Mode:

0: automatic recovery; 1: manual recovery

This option is for low frequency protection, dry protection, over-current protection, minimum power function; you can select the alarm restoration by A0-29. When you select 0 for automatic recovery, during fault warning displaying, you can also press the "RESET" button to stop operation; during fault warning displaying, you can press the "RESET" button to manually clear, you can also press "RESET" button to achieve stop operation.

H. PQ Curve Function

This model provides a self-defined PQ curve for users to set up five groups of PQ corresponding points according to the pump cases, to achieve real-time traffic speed, daily flow, cumulative flow, generating capacity, cumulative electricity consumption; of which by default, daily flow and generating capacity are calculated based on 7h in a day.

I. Status Check

When the photovoltaic pump is running, you can check U1-29 to confirm the current operating status.

Appendix1:Modbus Communication Protocol

● Communication Frame Structure

Communication data format is as follows: The byte composition: Including initiation bit, 8 data bit, check bit and stop bit.

Initiation Bit	Bit1	Bit2	Bit3	Bit4	Bit5	Bit6	Bit7	Bit8	Check bit	Stop bit
----------------	------	------	------	------	------	------	------	------	-----------	----------

One frame message must be transmitted as a continued data flow, and if there is a interval over 1.5 byte before ending, the receiving equipment will clear the half-baked information. And the next byte will be considered as the address field of a new frame. Similarly, if the interval between a new frame start-up and the former frame is smaller than 3.5 byte time, the receiving equipment will consider that it is the continuation of former one frame. Since the jumbled frame, the final CRC checking value is incorrect, which would lead to the communication mistake.

● Communication command and examples

Read command:03H,Read N words.Up to 20 words read in succession.

Example:The slave machine address is 01H,read 3 successive words of start address 2100H(U1-00), The structure of the frame is described as follows:

RTU Main machine command		RTU slave machine return message(normal)		RTU slave machine return message(abnormal)	
START	3.5 bytes	START	3.5 bytes	START	3.5 bytes
Slave address	01H	Slave address	01H	Slave address	01H
Command code	03H	Command code	03H	Command code	83H
start address high bits	21H	Return data numbers	06H	Fault code	04H
start address low bits	00H	high bit of 2100H	13H	CRC CHK low bits	40H
Data numbers high bits	00H	low bit of 2100H	88H	CRC CHK high bits	F3H
Data numbers low bits	03H	high bit of 2101H	00H	END	3.5 bytes
CRC CHK low bits	0FH	low bit of 2101H	00H		
CRC CHK high bits	F7H	high bit of 2102H	00H		
END	3.5 bytes	low bit of 2102H	00H		
		CRC CHK low bits	90H		
		CRC CHK high bits	A6H		
		END	3.5 bytes		

Write command:06H,Write a word data to the specified data address, this command can change the parameter of inverter.

Example:Write 1388Hto the address 3000H of the slave controller. The structure of the frame is described as follows:

RTU Main machine command		RTU slave machine return message(normal)		RTU slave machine return message(abnormal)	
START	3.5 bytes	START	3.5 bytes	START	3.5 bytes
Slave address	01H	Slave address	01H	Slave address	01H
Command code	06H	Command code	06H	Command code	86H
start address high bits	30H	Data address high bits	30H	Fault code	01H
start address low bits	00H	Data address low bits	00H	CRC CHK low bits	83H
Data high bits	13H	Data high bits	13H	CRC CHK high bits	AOH
Data low bits	88H	Data low bits	88H	END	3.5 bytes
CRC CHK low bits	8BH	CRC CHK low bits	8BH		
CRC CHK high bits	9CH	CRC CHK high bits	9CH		
END	3.5 bytes	END	3.5 bytes		

● **Communication Control Parameter Group Address Specification:**

Function Specification	Address Definition	Data Meaning Specification			R/W
Communication Given Frequency	0x3000 or 0x2000	0~60,000 is corresponding to 0.00Hz~600.00Hz			W/R
Communication Command Setting	0x3001 or 0x2001	0000H:No order 0001H:FWD running 0002H:REV running 0003H:FWD jog 0004H:REV jog	0005H:DEC stop 0006H:free stop 0007H:Fault reset 0008H:Running banned command 0009H:Running allowed command		W/R
State of Inverter	0x3002 or 0x2002	Bit0	0: stop	1:running	R
		Bit1	0:non-acc state	1: ACC	
		Bit2	0:non-dec state	1: DEC	
		Bit3	0: Forward	1: REV	
		Bit4	0: normal	1: fault	
		Bit8	0: normal	1: Sleep	
		Bit9	0: normal	1:Low frequency	

PV210 solar pump inverter user manual

Function Specification	Address Definition	Data Meaning Specification			R/W
		Bit10	0: normal	1: Dry run	
		Bit11	0: normal	1: Over current	
		Bit12	0: normal	1: Low power	
Frequency Inverter Fault	0x3003 or 0x2003	current inverter fault code(refer to fault code table)			R
Communication Given Upper	0x3004 or 0x2004	0~32000 is corresponding to 0.00Hz~320.00Hz			W/R
Communication Torque Setting	0x3005 or 0x2005	0~1000 is corresponding to 0.0~100.0%			W/R
The FWD Max Frequency limit in Torque Control	0x3006 or 0x2006	0~1000 is corresponding to 0.0~100.0%			W/R
The REV Max Frequency limit in Torque Control	0x3007 or 0x2007	0~1000 is corresponding to 0.0~100.0%			W/R
Communication Given PID Setting	0x3008 or 0x2008	0~1000 is corresponding to 0.0~100.0%			W/R
Communication Given PID Feedback	0x3009 or 0x2009	0~1000 is corresponding to 0.0~100.0%			W/R
AO output	0x3021 or 0x2021	0-10000 corresponds output 0-10V,0-20mA			R

Note: The other function code addresses refer to “Communication Address” of function code table. While using writing command (06 H), if the highest digit of parameter function code address domain is 0, it only write in the RAM of inverter, and on storage when power off; if the high half digit of parameter function code address is 1, it write in EEPROM, which means power off storage. For instance, F0 parameter group: 0X00XX (RAM); 0X10XX (EEPROM)

● List of fault code meanings for abnormal response information from salve machine:

Fault Code	Meanings	Fault Code	Meanings
1	Order code fault	7	Reserved
3	CRC checking fault	8	Inverter busy(EEPROM is storing)
4	Illegal address	9	Value over limit
5	Illegal data	10	Reserved parameters can't be modify
6	Unable to modify when running	11	Number of Bytes wrong when reading